

AYANEO Pocket S 说明书

适用于 AYANEO Pocket S
机型说明

AYANEO Pocket S
User Manual

For model of AYANEO Pocket S

AYANEO Pocket S



产品说明书

User Manual

AYANEO Pocket S 说明书

适用于 AYANEO Pocket S
机型说明

AYANEO Pocket S User Manual


For model of AYANEO Pocket S

Size 212×82mm

AYANEO Pocket S



*摇杆氛围灯配合 AYASpace APP，可以定义颜色、亮度状态等，具体功能配置以 AYASpace APP更新为准。
*Joystick ambient lighting with AYASpace APP, you can define the color, brightness status, etc. The specific function configuration is subject to the update of AYASpace APP.



*指纹功能支持以选购版本配置为准。
*Fingerprint functionality is supported based on the purchased version configuration.



AYANEO Pocket S 说明书

适用于 AYANEO Pocket S
机型说明

AYANEO Pocket S
User Manual

For model of AYANEO Pocket S

Size 212×82mm



*通过拨动性能切换开关切换机器性能策略，具体策略配置以 AYASpace APP 版本更新为准。
*Toggle the performance toggle switch to switch the machine performance policy, the specific policy configuration is subject to the AYASpace APP version update.

AYANEO

AYANEO Pocket S 说明书

适用于 AYANEO Pocket S 机型说明

AYANEO Pocket S User Manual

For model of AYANEO Pocket S

Size 212×82mm

开机 / 关机 / 重启 / * 指纹

关机状态下, 按住电源按键 "  " 约 3 秒后松开将 AYANEO Pocket S 开机。

开机状态下, 按住电源按键 "  " 约 2 秒弹出的菜单选择  将 AYANEO Pocket S 关机, 选择  AYANEO Pocket S 将重新启动。

* 指纹识别功能以选购 AYANEO Pocket S 版本配置为准。
确定选购版本支持指纹识别时, 需设置屏幕锁定才能正常设置使用指纹识别功能。

设置  >  安全> 屏幕锁定, 可选择设置图案, PIN 码或密码。然后在安全选项下选择指纹  , 输入密码或 PIN 确定安全性后即可设置并录入指纹。

Power On / Off / Restart / * Fingerprint

When in the shutdown state, press and hold the power button "  " for about 3 seconds and release to power on AYANEO Pocket S.

In the power-on state, press and hold the power button "  " for about 2 seconds to bring up the menu, select the  to turn off AYANEO Pocket S, and select the  to restart AYANEO Pocket S.

*Fingerprint recognition functionality is subject to the configuration of the purchased AYANEO Pocket S version.
When the purchased version supports fingerprint recognition, screen lock must be set to use fingerprint recognition.

Go to  > Security > Screen lock, and choose to set a pattern, PIN code, or password. Then, under security options, select fingerprint  , enter the password or PIN to confirm security, and proceed to set and enroll fingerprints.

睡眠唤醒

开机状态下, 点按电源按键 "  " 使 AYANEO Pocket S 进入睡眠状态。
睡眠状态下, 点按电源按键 "  " 将 AYANEO Pocket S 唤醒。如果已设置安全屏幕锁定, 需要绘制图案、输入密码或 PIN 码确定安全性后方可进入 OS 界面。如果已同时配置安全屏幕锁定和指纹, 轻触电源按钮完成指纹识别后即可快速唤醒并进入 OS 界面。

关机后重新开机, 或者开机状态下重启后, 需要重新验证安全屏幕锁定安全性才可使用指纹解锁屏幕。

音量

点按音量键 "  " 音量逐级增加, 长按则连续增加音量。点按音量键 "  " 音量减小。在设置  >  提示音和振动, 可对应调节媒体音量、通知音量、闹钟音量等。

Sleep / Wake

In the power-on state, press the power button "  " to put AYANEO Pocket S to sleep.
In sleep mode, press the power button "  " to wake up AYANEO Pocket S. If a secure screen lock is set, you need to draw a pattern, enter a password, or PIN to confirm security before accessing the OS interface. If both secure screen lock and fingerprint are configured, a light touch on the power button after fingerprint recognition quickly wakes up and enters the OS interface.

After shutting down and restarting or restarting in the power-on state, security screen lock verification is required for fingerprint unlocking.

Volume

Press the volume button "  " to incrementally increase the volume; long press for continuous volume increase. Press the volume button "  " to decrease the volume. In "Settings  >  Sound & vibration , adjust media volume, notification volume, alarm volume, etc.

文本输入

需要输入文本时, 点击输入框即自动呼出触摸键盘, 使用触控输入文本。

下拉菜单

在屏幕顶部第一次向下滑动呼出下拉菜单, 可快速切换 WLAN、蓝牙等设置。再次向下滑动显示完整下拉快捷菜单, 滑动亮度调节滑块进行屏幕亮度调节, 可进行快捷按钮配置等操作。



网络 / 蓝牙

AYANEO Pocket S 支持 WLAN 网络, 需要通过 WLAN 连接网络时, 设置  进入设置菜单主页 >  网络和互联网> 互联网 , 进入并选取需要连接网络名称, 输入连接密码后点击“连接”连接到 WLAN 网络, 点击右侧开关图标  可以开启或关闭 WLAN 功能。

需连接蓝牙设备时, 设置菜单主页选择  已连接的设备> 新配对设备, 在搜索出列表点击需要连接的蓝牙设备。

Text Input

When entering text, click on the input box to automatically bring up the touch keyboard for text input.

Dropdown Menu

Swipe down at the top of the screen for the first time to bring up the dropdown menu, allowing quick switching of WLAN, Bluetooth, and other settings. Swipe down again to display the complete dropdown quick menu; slide the brightness adjustment slider for screen brightness adjustment and configure quick buttons.



Network / Bluetooth

AYANEO Pocket S supports WLAN network, when you need to connect to the network via WLAN, Settings  Enter the Settings Menu >  Network & Internet> Internet, enter and select the name of the network you need to connect to, enter the connection password and click "Connect" to connect to the WLAN network, and then click the switch icon  on the right side to turn on or off the WLAN function.

To connect a Bluetooth device, select  Connected Devices > Pairing New Device, from the main page of the Settings menu, and then click the Bluetooth device you want to connect to in the search list.

AYANEO Pocket S 说明书

适用于 AYANEO Pocket S 机型说明

AYANEO Pocket S User Manual

For model of AYANEO Pocket S

Size 212×82mm

电池和充电

请使用附带的适配器对 AYANEO Pocket S 进行充电, 切勿使用无安全认证适配器进行充电, 可能会造成内部元件损坏和不可预知的危险。

当 Type-C 线插入电源时应当避免皮肤与插头长时间接触, 否则可能会引起不适或受伤。请勿尝试自行更换 AYANEO Pocket S 电池, 您可能会损坏电池, 从而导致过热可能引发火灾和人身伤害。

AYANEO Pocket S 的锂离子电池应由 AYANEO 提供相关服务或进行回收, 它必须和家庭垃圾分开回收处理。请按照当地的环保法规来处理电池。电池只能由 AYANEO 或者 AYANEO 授权服务提供商进行更换, 用错误型号电池更换会有爆炸危险。

清洁

请使用不起绒的布来清洁 AYANEO Pocket S , 切勿使任何一个开口处受潮或使用气雾喷剂、溶剂或研磨剂。

Battery and Charging

Please use the provided adapter to charge AYANEO Pocket S. Do not use uncertified adapters for charging, as it may cause internal component damage and unpredictable dangers.

When the Type-C cable is plugged into the power source, avoid prolonged skin contact with the plug to prevent discomfort or injury. Do not attempt to replace the battery in AYANEO Pocket S on your own, as it may damage the battery, leading to overheating and potential fire hazards.

AYANEO Pocket S's lithium-ion battery should be serviced or recycled by AYANEO, separated from household waste. Follow local environmental regulations for battery disposal. Battery replacement can only be done by AYANEO or an authorized service provider; using the wrong battery model may pose an explosion risk.

Cleaning

Use a non-lint cloth to clean AYANEO Pocket S. Avoid moisture in any openings or the use of aerosol sprays, solvents, or abrasives.

医疗设备干扰

AYANEO Pocket S 内部部分元件包含磁体及无线电发射电磁场, 这些电磁场可能会干扰医疗设备、心脏起搏器、除颤器或其他医疗设备。请在医疗设备和 AYANEO Pocket S 之间保持一定的安全距离。请咨询您的医师和医疗设备制造商以获得医疗设备信息。如怀疑 AYANEO Pocket S 干扰您的心脏起搏器、除颤器或者其他医疗设备, 请停止使用 AYANEO Pocket S。

AYANEO 保证所附硬件产品和配件, 从原先零售购入的日期起一年内, AYANEO 对正常磨损不作担保, 对事故或滥用造成的损坏也不做担保。若要获取服务, 请访问 AYANEO 商城或者 AYANEO 授权服务提供商, 可用的服务选项取决于请求的服务所在的国家或地区, 并且可能限制为销售的原始国国家和地区。可能需要支付通话费用和国际运费, 这取决于您的位置。

当您根据保修服务政策提交有效的索赔时, AYANEO 将为您的 AYANEO Pocket S 酌情进行维修, 更换或退款。您享有的保修权益是附加在本地消费者法律所提供的权力以外的。当您根据本保修政策提出索赔时, 可能需要提供购买凭证的详细信息。

Medical Device Interference

AYANEO Pocket S contains internal components that include magnets and emit electromagnetic fields. These fields may interfere with medical devices, pacemakers, defibrillators, or other medical devices. Maintain a safe distance between medical devices and AYANEO Pocket S. Consult your physician and the manufacturer of medical devices for information. If you suspect that AYANEO Pocket S is interfering with your pacemaker, defibrillator, or other medical device, stop using AYANEO Pocket S.

AYANEO guarantees hardware products and accessories for one year from the original retail purchase date. AYANEO does not guarantee normal wear and tear or damage caused by accidents or misuse. For service, visit the AYANEO store or an authorized service provider. Available service options depend on the country or region where the service is requested and may be limited to the original country and region of sale. Call charges and international shipping fees may apply, depending on your location.

When submitting a valid claim under the warranty service policy, AYANEO will repair, replace, or refund your AYANEO Pocket S at its discretion. Your warranty rights are additional to the powers provided by local consumer laws. When filing a claim under this warranty policy, detailed information about the purchase receipt may be required.

支持

更多支持和故障排除信息、请访问 www.ayaneo.com.cn。

Support

For more support and troubleshooting information, please visit www.ayaneo.com.

www.ayaneo.com.cn

www.ayaneo.com

AYANEO Pocket S 说明书

适用于 AYANEO Pocket S 机型说明

AYANEO Pocket S User Manual

For model of AYANEO Pocket S

Size 212×82mm

说明

一、请妥善保管本三包凭证,本三包凭证和购机发票一起作为保修凭证,在保修期内享受免费保修。

二、“三包”有效凭证

在“三包”有效期内产品出现故障,消费者需凭购机发票和此三包凭证享受免费维修服务,所修理产品机身号码同三包凭证上的产品机身号码必须一致。如无购机发票,则以产品机身号码的生产出厂日期作为消费者产品“三包”有效期的起始时间。如两者全无的消费者,则不能享受免费维修服务,我司将实行收费维修服务。

三、根据《部分商品修理更换退货责任规定》,属下列情况之一者,不实行“三包”,但可实行收费维修:

- 超出本公司产品保修期范围内的;
- 无法同时出示购机发票和填写保修凭证,或保修凭证上与维修产品的型号、机身号码不符或涂改;
- 非承担三包的修理者进行修理或者拆卸、改装等引起的故障和损坏;
- 未按照产品使用说明的要求使用、维护、保管而造成的故障和损坏;
- 使用非本公司所制造的产品配件引起的产品故障和损坏;
- 由于跌落、移动、运输等非产品质量原因引起的故障和损坏;
- 油烟、灰尘、受潮、直射阳光等恶劣条件下使用产生的故障和损坏;
- 由于雷击、水灾、火灾、地震、风灾等自然灾害及异常电压、公害、化学物质的侵蚀而造成的故障和损坏;
- 使用盗版软件造成损坏的;
- 使用过程中感染病毒造成损坏的。

四、超过“三包”有效期或“三包”责任范围的,按照 AYANEO 规定的收费标准实施收费服务。

在线自助服务: www.ayaneo.com.cn

技术支持热线: 400-039-8088

维修记录项目

送修日期	故障描述 故障原因 处理结果	使用配件	交验日期	修理单位 名称	维修人员 签字

AYANEO 商品三包凭证

商品名称 _____
商品商标 _____
商品序列号 _____
商品产地 _____

销售单位名称 _____
销售单位地址 _____
销售单位邮政编码 _____
销售发票号码 _____
销售日期 _____

消费者姓名 _____
消费者地址 _____
消费者邮政编码 _____
消费者联系电话 _____

修理单位名称 _____
修理单位地址 _____
修理单位邮政编码 _____
修理单位联系电话 _____

AYANEO 严格按照《微型计算机商品修理更换退货责任规定》,为购买 AYANEO 商品的消费者实行三包。若服务条款与三包规定有不符之处,以三包规定及三包凭证内容为准。对于执行特别三包目录的地区,AYANEO 承诺遵守当地的相关规定。

产品标签

销售单位印章
