

AYANEO FLIP 说明书

适用于 AYANEO FLIP  
机型说明

AYANEO FLIP  
User Manual

For model of AYANEO FLIP

# AYANEO FLIP



产品说明书

User Manual

AYANEO FLIP 说明书

适用于 AYANEO FLIP  
机型说明

AYANEO FLIP  
User Manual

For model of AYANEO FLIP


Size 252×132mm

AYANEO FLIP<sup>KB</sup>



AYANEO FLIP<sup>DS</sup>



AYANEO FLIP<sup>KB</sup>



AYANEO FLIP<sup>DS</sup>






AYANEO FLIP 说明书

适用于 AYANEO FLIP  
机型说明

AYANEO FLIP  
User Manual

For model of AYANEO FLIP

Size 252×132mm



AYANEO

# AYANEO FLIP 说明书

## 适用于 AYANEO FLIP 机型说明

## AYANEO FLIP User Manual

For model of AYANEO FLIP

Size 252×132mm

### 使用 开机关机和指纹

• 关机状态下, 按电源按键“实体按键  ”约 1 秒将 AYANEO FLIP 开机, 通电后电源键指示灯常亮白色。

• 开机状态下, 桌面视图 > 视图  > 电源  > 关机  将 AYANEO FLIP 关机。  
长按电源键“实体按键  ”约 8 秒强制关闭 AYANEO FLIP。  
注: 正常使用场景下不推荐强制关闭操作, 此操作可能会造成数据损坏。

• 支持指纹识别, 需要登陆微软账户或设置本地账户及密码后启动 Windows Hello 生物识别功能才可以正常设置使用指纹识别功能。

桌面视图 > 视图  > 设置  > 账户  > 登录选项  > 指纹识别 (Windows Hello)  , 录入启动指纹安全登录, 每个账户最大支持录入十个指纹。


### 休眠和唤醒

• 开机状态下, 点按电源按键“实体按键  ”将 AYANEO FLIP 进入休眠, 或者点击桌面视图 > 视图  > 电源  > 休眠  。

• 休眠状态下, 点按电源按键“实体按键  ”将 AYANEO FLIP 唤醒。Windows Hello 已设置指纹安全登录的, 点按电源键唤醒屏幕后再轻触识别指纹后进入 OS 界面, 无需输入 PIN 及密码登录, 不同环境界面下需要等待 1~3 秒才可以亮屏完成唤醒。

### 光学手指导航鼠标

• AYANEO FLIP 支持模拟鼠标, 使用时手指轻触光学手指导航滑动可控制鼠标光标移动, 单击按下或者轻触点击触发鼠标左键, 长按约 0.5 秒以上触发鼠标右键。



### 文本输入 (仅 AYANEO FLIP KB)

• 需要输入文本时, 可使用 AYANEO FLIP KB 自带的 77 键 QWERTY 物理键盘, 独立快捷功能键, 支持音量调节、亮度调节、截图、媒体播放控制、投屏模式切换、应用全屏切换、计算器, 配合 Fn 热键, 支持 F1-F12 功能, 可满足文本录入及不同场景使用需求。



### 文本输入 (AYANEO FLIP DS)

• 需要输入文本时, 桌面界面下长触底部状态栏弹出菜单选择  > “触摸键盘  ”选择“始终”将触摸键盘始终显示至状态栏, 点击  图标呼出触摸键盘, 使用触控输入文本。



### 副屏 (仅 AYANEO FLIP DS)

• 除主屏外, AYANEO FLIP DS 还额外配备一块 3.5 英寸触控显示屏, 屏幕支持单点、滑动触敏, 默认以扩展模式作为副屏显示, 配合 AYASpace 软件和专用的副屏交互按键  , 可配置显示 AYANEO FLIP DS 运行时的各项实时信息。

• 具体显示配置参数及界面交互请以最新 AYASpace 软件版本更新为准。

### 音量

• 点按音量  “音量逐级增加, 长按则连续增加音量, 点按音量  ”音量减小, 长按连续减小音量, 或者桌面界面点击右上角音量图标  在弹窗菜单滑动调节音量大小  。

### WLAN 和蓝牙

• 需要连接 WLAN 网络时, 桌面界面点击右上角 WLAN 图标  > 在弹窗菜单点击  “进入并选取需要连接网络名称, 输入密码后点击“下一步”连接到 WLAN 网络。

• 需要连接蓝牙设备时, 点击屏幕右下角蓝牙图标  > 添加蓝牙设备 >  点选搜索需要连接的蓝牙设备。




### 灯效

• AYANEO FLIP KB 支持调节键盘背光和电源键指示灯, 灯效配合 AYASpace 应用可自定义颜色、亮度、状态等, AYANEO FLIP DS 仅支持调节电源键指示灯, 具体设置以 AYASpace 版本更新为准。

### 电池和充电

• AYANEO FLIP 充电时, 顶部指示灯红色常亮, 请使用附带的适配器对 AYANEO FLIP 进行充电, 切勿使用无安全认证适配器对 AYANEO FLIP 充电, 可能会造成内部元件损坏和不可预知的危险。




• 当 Type-C 线插入电源时应当避免皮肤与插头长时间接触, 否则可能会引起不适或受伤, 请勿尝试自行更换 AYANEO FLIP 电池, 您可能会损坏电池, 从而导致过热可能引发火灾和人身伤害。

• AYANEO FLIP 的锂离子电池应由 AYANEO 提供相关服务或进行回收, 它必须和家庭垃圾分开回收处理, 请按照当地的环保法规来处理电池, 电池只能由 AYANEO 或者 AYANEO 授权服务提供商进行更换, 用错误型号电池更换会有爆炸危险。

### 清洁

• 请使用不起绒的布来清洁 AYANEO FLIP , 切勿使任何一个开口处受潮或使用气雾喷射、溶剂或研磨剂。

### 注意事项

- 本产品的操作系统为微软公司出品的 Windows 11 64 位家庭版, 在桌面界面下, 可以通过触控屏幕进行 Windows 的基本操作。
- 桌面模式下三指同时点按住屏幕 向上滑动, 调出任务视图可快速切换应用及新建桌面, 向下滑动则最小化所有应用。
- 应用程序出现无响应, 无法正常关闭的情况下, 长按视图  在弹出菜单选择 任务管理器, 在任务管理器中选中无响应的进程进行“结束任务”操作。

### 医疗设备干扰

• AYANEO FLIP 内部分元件包含磁体及无线电发射电磁场, 这些电磁场可能会干扰医疗设备、心脏起搏器、除颤器或其他医疗设备, 请在医疗设备和 AYANEO FLIP 之间保持一定的安全距离, 请咨询您的医师和医疗设备制造商以获得医疗设备信息, 如怀疑 AYANEO FLIP 干扰您的心脏起搏器、除颤器或其他医疗设备, 请停止使用 AYANEO FLIP 。

### 保修

- AYANEO 保证所附硬件产品和配件, 从最先零售购入的日期起一年内, AYANEO FLIP 对正常磨损不作担保, 对事故或滥用造成的损坏也不能担保, 若要维修服务, 请访问 AYANEO 商城或者 AYANEO 授权服务提供商, 可用的服务选项取决于请求的服务所在的国家或地区, 并且可能限制为销售的原始国家和地区, 可能需要支付通话费用和国际运费, 这取决于您的位置。
- 当您根据保修服务政策提交有效的索赔时, AYANEO 将为您的 AYANEO FLIP 酌情进行维修, 更换或退款, 您享有的保修权益是附加在本地消费者法律所提供的权力以外的, 当您根据本保修政策提出索赔时, 可能需要提供购买凭证的详细信息。

### 支持

- 更多支持和故障排除信息、驱动软件、及最新的 AYASpace 下载, 请访问 [www.ayaneo.com.cn](http://www.ayaneo.com.cn) 。

### FCC 合规

- 此设备符合 FCC 规则第十五部分中的规范标准。

操作设备须符合以下两个条件:  
(1) 此设备不会导致有害干扰;  
(2) 此设备可承受任何外来干扰, 包括可能导致非预期操作的干扰。

### 欧盟合规

AYANEO 特此声明本无线设备符合指令。  
2014/53/EU 规范。

# AYANEO FLIP 说明书

## 适用于 AYANEO FLIP 机型说明

# AYANEO FLIP User Manual

For model of AYANEO FLIP

Size 252×132mm







### Usage

#### Power On, Power Off, and Fingerprint Recognition

• In the power-off state, press the "physical power button"  for about 1 second to power on AYANEO FLIP. The power button indicator will stay lit in white after powering on.

• In the power-on state, go to the desktop view > Window  > Power  > Shutdown  > Power off  to power off AYANEO FLIP. Press and hold the "physical power button"  for about 8 seconds to force shut down AYANEO FLIP. Note: Forced shutdown is not recommended in normal usage scenarios, as it may result in data loss.

• Fingerprint recognition is supported and requires logging in to a Microsoft account or setting up a local account and password to enable Windows Hello biometric recognition.

Go to desktop view > Window  > Settings  > Accounts  > Sign-in options  > Windows Hello  > Fingerprint recognition (Windows Hello)  to enroll for secure fingerprint login. Each account supports a maximum of ten fingerprints.


### Sleep and Wake

• In the power-on state, tap the "physical power button"  to put AYANEO FLIP to sleep, or click on the desktop view > Window  > Power  > Sleep .

• In the sleep state, tap the "physical power button"  to wake up AYANEO FLIP. If Windows Hello fingerprint secure login is set up, tap the power button to wake the screen and then lightly touch the fingerprint sensor to enter the OS interface without entering a PIN or password. The screen may take 1-3 seconds to light up during different environmental interfaces.

### Optical Finger Navigation Mouse

• AYANEO FLIP supports simulated mouse operation. Use your finger to gently touch the optical finger navigation to control the mouse cursor movement. Click or lightly touch to trigger the left mouse button, and press and hold for about 0.5 seconds to trigger the right mouse button.






### Text Input (AYANEO FLIP KB Only)

• When text input is required, you can use the built-in 77-key QWERTY physical keyboard of AYANEO FLIP KB. It features independent shortcut function keys, supporting volume adjustment, brightness adjustment, screenshot, media playback control, screen mirroring mode switching, application full-screen switching, and calculator. With the Fn hotkey, it supports F1-F12 functions, meeting the needs of text input and various usage scenarios.



### Text Input (AYANEO FLIP DS Only)

• When text input is required, on the desktop interface, long-press the bottom status bar to bring up the menu. Choose "Taskbar Settings" , then select "Touch Keyboard" , and choose "Always" to keep the touch keyboard visible on the status bar. Click the  to summon the touch keyboard and use touch input for typing.



### Lighting Effects

• AYANEO FLIP KB supports adjusting the keyboard backlight and power button indicator light. The lighting effects can be customized using the AYASpace application for color, brightness, and status. AYANEO FLIP DS only supports adjusting the power button indicator light, and specific settings are subject to updates in the AYASpace version.

### Battery and Charging

• When AYANEO FLIP is charging, the top indicator light stays red.. Use the provided adapter to charge AYANEO FLIP and avoid using uncertified adapters, as it may cause internal component damage and pose unpredictable risks.



Type-C (support for charging)

• When the Type-C cable is plugged into the power source, avoid prolonged skin contact with the plug, as it may cause discomfort or injury. Do not attempt to replace the battery of AYANEO FLIP on your own, as you may damage the battery, leading to overheating, which could potentially result in fire hazards and personal injury.

• The Lithium-ion battery of AYANEO FLIP should be serviced or recycled by AYANEO. It must be disposed of separately from household waste. Please follow local environmental regulations for battery disposal. The battery replacement should only be performed by AYANEO or an authorized service provider. Replacing it with the wrong battery model may pose an explosion risk.


### Cleaning

• Please use a non-lint cloth to clean AYANEO FLIP. Avoid getting any openings wet and refrain from using aerosol sprays, solvents, or abrasives.

### Notes

• This product operates on Microsoft's Windows 11 64-bit Home edition. In the desktop interface, basic Windows operations can be performed using the touchscreen.

• In desktop mode, swiping up on the screen with three fingers simultaneously brings up the task view for quick app switching and desktop creation. Swiping down minimizes all applications.

• In case of unresponsive applications that cannot be closed normally, long-press the window , select "Task Manager" from the pop-up menu, and choose "End Task" for the unresponsive process.

### Medical Device Interference

• Certain components inside AYANEO FLIP emit magnetic and radio frequency electromagnetic fields that may interfere with medical devices such as pacemakers, defibrillators, or other medical equipment. Maintain a safe distance between medical devices and AYANEO FLIP. Consult your physician and the medical device manufacturer for relevant information. If you suspect interference with your pacemaker, defibrillator, or other medical devices, discontinue use.

### Warranty

• AYANEO guarantees the attached hardware products and accessories for one year from the original retail purchase date. Normal wear and tear are not covered, and damage resulting from accidents or misuse is not guaranteed. For service, visit the AYANEO store or an authorized service provider. Available service options depend on the country or region of service request and may be limited to the original sales countries and regions. Charges for calls and international shipping may apply, depending on your location.

• When submitting a valid claim under the warranty service policy, AYANEO will repair, replace, or refund your AYANEO FLIP at its discretion. Your warranty rights are in addition to the rights provided by local consumer laws. When filing a claim under this warranty policy, detailed purchase receipt information may be required.

### Support

• For more support, troubleshooting information, driver software, and the latest AYA Space downloads, visit [www.ayaneo.com](http://www.ayaneo.com).

### FCC Compliance

This device complies with the specifications in Part 15 of the FCC rules.

Operation of the device must meet the following two conditions:

- (1) The device must not cause harmful interference.
- (2) The device must accept any interference received, including interference that may cause undesired operation.

### EU Compliance

AYANEO hereby declares that this wireless device complies with the directive 2014/53/EU specifications.

# AYANEO FLIP 说明书

## 适用于 AYANEO FLIP 机型说明

# AYANEO FLIP User Manual

For model of AYANEO FLIP

Size 252×132mm

### 说明

一、请妥善保管本三包凭证，本三包凭证和购机发票一起作为保修凭证，在保修期内享受免费保修。

### 二、“三包”有效凭证

在“三包”有效期内产品出现故障，消费者需凭购机发票和此三包凭证享受免费维修服务，所修理产品机身号码同三包凭证上的产品机身号码必须一致。如无购机发票，则以产品机身号码的生产出厂日期作为消费者产品“三包”有效期的起始时间。如两者全无的消费者，则不能享受免费维修服务，我司将实行收费维修服务。

三、根据《部分商品修理更换退货责任规定》，属下列情况之一者，不实行“三包”，但可实行收费维修：

- 超出本公司产品保修期范围内的；
- 无法同时出示购机发票和填写保修凭证，或保修凭证上与维修产品的型号、机身号码不符或涂改；
- 非承担三包的修理者进行修理或者拆卸、改装等引起的故障和损坏；
- 未按照产品使用说明的要求使用、维护、保管而造成的故障和损坏；
- 使用非本公司所制造的产品配件引起的产品故障和损坏；
- 由于跌落、移动、运输等非产品质量原因引起的故障和损坏；
- 油烟、灰尘、受潮、直射阳光等恶劣条件下使用产生的故障和损坏；
- 由于雷击、水灾、火灾、地震、风灾等自然灾害及异常电压、公害、化学物质的侵蚀而造成的故障和损坏；
- 使用盗版软件造成损坏的；
- 使用过程中感染病毒造成损坏的。

四、超过“三包”有效期或“三包”责任范围的，按照 AYANEO 规定的收费标准实施收费服务。

在线自助服务：www.ayaneo.com.cn

技术支持热线：400-039-8088

### 维修记录项目

送修日期	故障描述 故障原因 处理结果	使用配件	交验日期	修理单位 名称	维修人员 签字

### AYANEO 商品三包凭证

商品名称 \_\_\_\_\_  
商品商标 \_\_\_\_\_  
商品序列号 \_\_\_\_\_  
商品产地 \_\_\_\_\_

销售单位名称 \_\_\_\_\_  
销售单位地址 \_\_\_\_\_  
销售单位邮政编码 \_\_\_\_\_  
销售发票号码 \_\_\_\_\_  
销售日期 \_\_\_\_\_

消费者姓名 \_\_\_\_\_  
消费者地址 \_\_\_\_\_  
消费者邮政编码 \_\_\_\_\_  
消费者联系电话 \_\_\_\_\_

修理单位名称 \_\_\_\_\_  
修理单位地址 \_\_\_\_\_  
修理单位邮政编码 \_\_\_\_\_  
修理单位联系电话 \_\_\_\_\_

AYANEO 严格按照《微型计算机商品修理更换退货责任规定》，为购买 AYANEO 商品的消费者实行三包。  
若服务条款与三包规定有不符之处，以三包规定及三包凭证内容为准。对于执行特别三包目录的地区，  
AYANEO 承诺遵守当地的相关规定。

### 产品标签

### 销售单位印章
